



Fujitsu RAC and VRF systems to KNX Interface with binary inputs (to remote controller)

The Fujitsu-KNX gateway allows fully bi-directional communication between Fujitsu RAC and VRF systems and KNX installations.

Additionally, four potential-free binary inputs provide the possibility to integrate external devices, such as window contacts or presence detectors, that allows launching internal functions focused to improve energy efficiency.

FEATURES

KNX certified.

Configured by ETS standard configuration tool.

Reduced dimensions allowing a quick installation inside the Air Conditioner unit.

Offered all the required DPT objects to be compatible with all KNX thermostats in the market.

Energy efficiency functions, such as "timeout", "open window" or "Occupancy". Costs related to HVAC systems in a building are one of the highest and these functions allow to reduce them.

Smooth integration of KNX thermostats allowing the control of the AC unit by the own temperature sensor of the thermostat.

Simultaneous control of the AC unit by the IR remote controller and by KNX.


Total control and monitoring of the AC unit from KNX, including AC unit's internal variables, running hours counter (for filter maintenance control) and error indication.

Up to 5 scenes can be saved and executed from KNX.



Use Case

Integration of Fujitsu Air Conditioner Systems into KNX with Binary Inputs.



Description

DIRECT CONNECTION TO INDOOR UNITS

The gateway is wired directly to an indoor unit. This allows not only the control of the main AC functions such as operating mode, fan speed, temperature setpoint...but the monitoring of errors, alarms and some internal variables.

EASY TO SET UP BY ETS (STANDARD KNX TOOL)

The connection between the two networks is quickly set up in the ETS configuration tool using the product database available to download. Thanks to the high number of supported KNX DPTs and the KNX certification, the gateway ensures interoperability with any KNX device in the market.

Technincal Documentation

User Manual	General information about this product	Download
Installation Manual	Learn how to install the device in your project	Download
HVAC Compatibility tool	Find the appropriate solution for your HVAC integration	Open
HVAC Compatibility	Check your HVAC compatibility	Download
EC Declaration of Conformity	Check the product certification	Download

Programming Tool

ETS Data Base	Configuration tool	Download
---------------	--------------------	----------

Case Study

Case Study	Learn how Intesis gateways make integration easy	Open
------------	--	------

Commercial Documentation

Marketing Datasheet	Discover all the integration solutions for Fujitsu	Download
Intesis Brochure	Know more about the Intesis current available products	Download

HVAC Compatibility

Ensure the compatibility of this gateway with your AC model by visiting <https://compatibility.intesis.com/>

Compatible AC models

ASHG - LMTA | ASY - UI-LF | ASY - UI-LM | ASY - UI-LMC | ASY - UI-LT | ASY - UI-LU | ASYA - LCC | ASYA - LEC | ASYA - LKC | ASYB - LDC | ASYG - LTCA | ASYG - LTCB | ASYG - LECA | ASYG14LECA | ASYG - LECB | ASYG - LFCA | ASYG - LFCC | ASYG - LJCA | ASYG - LMCA | ASYG - LMCB | ASYG - LMCE | ASYG - LVCB | ASYG - LUCA | ASAG - LJCA | ASU - RLF1 | ASU - RLF1 | ASU - RMLQ | ASYG18LFC | ASYG24LFCC | ASYG - LMC | ASYG - LU | AS - UFADR | AS - UFAJR | ASYA - GACH | ASYA - LACH | ASYA - LATF | ASYE - GACH | ASYE - LACF | ASYE - LACH | ACG - UiA-LB | ACG - UiA-LL | ACG - UiA-LM | ACH - UiA-LL | ACY - UiA-LB | ACY - UiA-LH | ACY - UiAT-LH | ACY - H UiAT-LH | ACY - UiA-LL | ACY - UiA-LM | ACY - UiAT-LM | ACY - Ui-MI | ACY71UiB | ACY - Ui | ARH - LUAN | ARHG - LHTA | ARHG - LHTBP | ARHG - LLTB | ARHG - LMLA | ARHG - LMLE | ARY - LUAN | ARY - UUAK | ARY - UUAN | ARYA - LCTU | ARYC - LCTU | ARYC - LHTA | ARYF - LBLU | ARYF - LBTU | ARYG - LHTA | ARYG - LLTA | ARYG - LLTB | ARYG - LMLA | ARYG - LMLE | ARU - RLF | ARU - RML | ARY - LUAB | ARY - LUAD | ARYG - LSL | ARYG - LTT | ARYG - LTTB | ARYG18LLTB | ARYG - LML | AR - UFAAR | ARXA - GALH | ARXA - GBLH | ARXA - LALR | ARXA - LATF | ARXA - LATH | ARXA - LBLR | ARXB - GALH | ARXB - LALF | ARXB - LALH | ARXB - LATF | ARXB - LATH | ARXB - LATR | ARXC - GATH | ARXC - LATF | ARXC - LATH | ARXD - GALH | ARXD - LATH | ARXK - GALH | ARXK - GCLH | AUG - FUAS | AUG - UUAS | AUT - UUAS | AUHG - LRLA | AUHG - LRLB | AUHG - LRLE | AUU - RML | AUU - UiA | AUU - UiA-LB | AUU - UiA-LR | AUU - UiAT-LR | AUU - UiA-LV | AUU - LUAS | AUU - UUAS | AUUA - LATN | AUUA - LBLU | AUUA - LCLU | AUUF - LAL | AUUF - LBL | AUUG - LRLA | AUUG - LRLE | AUUG - LVLA | AUUG - LVLB | AUU - RLM | AUUG - LVL | AUUG - LVLBB | AUUG - LRL | AUUG18LVLBB | AUUG - LVL | AU - UFAAR | AU - UFARR | AU - UFASR | AUUA - LATF | AUUA - GALH | AUUA - LALH | AUXB - GALH | AUXB - LALH | AUXB - LATF | AUXD - GALH | AUXD - LALH | ABHG - LRTA | ABHG - LRTE | ABHG - LVTA | ABY - UiA-LR | ABY - UiA-LV | ABY - UiAT-LR | ABYA - LBT | ABYA - LCT | ABYF - LBT | ABYG - LRTA | ABYG - LRTE | ABYG - LVTA | ABYG - LVTB | AGY - UiAT-LH | AGYF - LAC | AGYG - LVCA | AGYG - LVCB | ABYG - LVT | ABYG - LRTE | ABYG45LRTA | ABYA - GATH | ABYA - LATF | ABYA - LBTH | AWYA - LATF | AGY - Ui-LV | AGU - RLF | AGY - Ui-MI | AGYG - LVC | ASU18CL | ASU24CL1 | ASU - CLX1 | ASU - RLF | ASU - RLF | ASU - RLF1 | ASU - RLF1 | ASU - RLS | ASU - RLS2 | ASU - RLS3 | ASU - RLX | ASU - RLB | ASU - RLXB | ASU - RMLQ | ARU - RLF | ARU - RML | ARU - RMLQ | AUU - RLF | AUU - RML | AUU - RCLX | AGU - RLF | ABU - RSLX | ABU - RULX | ASAG - LJCA | AUAG - LRLC-A | ASTG - JECB | ASTG12JECB | ASTG - CMCA | ASTG - CMCA | ASTG - LVCA | ASTG18JVCA | ASTG - JFCC | ASTG - KMCA | ASTG - KMCA | ASTG - LVCC | ASTG - LFCC | ASTG - KUCA | ASTG - LUCB | ASTG12LVCB | ASTG - LFCA | ASTG - LFCB | ASTG - LUCA | AGTV - LAC | ABTG - LVTA | ABTG - LVTC | ABTA - LBT | ABTA - LAT | ABTA - LCTU | ABTG - LRTA | AUTG - LVLA | AUTG - LVLG | AUTA - LBLU | AUTA - LCLU | AUTG - LRLA | ARTG - LLTA | ARTA - LBTU | ARTA - LATU | ARTG - LMLC | ART - LUAK | ART - TUAJ | ART - UUAK | ART - UUAN | ARTC - LATU | ARTG - LDTA | ARTG - LHTA | ARTG - LHTB | ARTG - LHTC | ARTG - LHTDP | ARTG -

LL | ARTG - LLLB | ARYA - LBTU | ASTG18JVCA | ASTG - KUCA | ASTG12LVCB | ARSA25FMTA | ARSA50FMTB | ARSA60FHTB | ARSA60UHTB | ASBA - LFCA | AUBG - LVLA | ARBG - LLTA | ASBG - LJLC | ASBG - LMCA | ASBG - LFCA | ABBG - LVTA | AGBG - LVCA

FUJI ELECTRIC AC models

RSA - LKC | RSG - LTCA | RSG - LTCB | RSG - LECA | RSG14LECA | RSG - LMCA | RSA - LEC | RSG - LECB | RSG - LUCA | RSG - LJCA | RSG - LFCA | RSG - LFCC | RD - CC | RD - EC | RD - HC | RD - LAN | RD - UA | RD - TC | RDA - LALU | RDA - LATN | RDA - LCTU | RDA - LBTU | RDC - LCTU | RDC - LHTA | RDF - LALU | RDF - LBLU | RDF - LBTU | RDG - LHTA | RDG - LLTA | RDG - LLTB | RDG - LMLA | RDG - LMLE | RC - UA | RCA - LATN | RCA - LATU | RCA - LBLU | RCA - LCLU | RCF - LAL | RCF - LBL | RCG - LRLA | RCG - LRLE | RCG - LVLA | RCG - LVLB | RGF - LAC | RGG - LVCB | RGG - LVCA | RYG - LVTA | RYG - LVTB | RYF - LBT | RYFF - LBT | RYG - LRTE | RYG - LRTA | RYA - LBT | RYA - LCT | RCA - FRTA-S | RCA - URTA-S | RDA60FHTB-S | RDA60UHTB-S | RDA - FMTA-S | RDA - FMTB-S | RDA - UMTA-S | RDA - UMTB-S | RDA - OUMTB-S

GENERAL AC models

ASGA - AET 1 | ASGA - FMTA 1 | ASGA - FTTA 1 | ASGA - FTTA-A 1 | ASGA - JCC 1 | ASGG - LFCD 1 | ASGG - LJCA 1 | ASHA - LEC 1 | ASHA - LKC 1 | ASHB - LDC 1 | ASHG - LE 1 | ASHG14LE1 | ASHG - LECA 1 (except 07/12) | ASHG 7/12 LECA 1 | ASHG - LECB 1 | ASHG - LF 1 | ASHG - LFCA 1 | ASHG - LFCC 1 | ASHG - LFCD 1 | ASHG - LJ 1 | ASHG - LJCA 1 | ASHG - LMCA 1 | ASHG - LT 1 | ASHG - LTCA 1 | ASHG - LTCB 1 | ASHG - LU 1,2 | ASHG - LUCA 1 | ASG - UFADR 1 | ASG - UFAJR 1 | ASGA - LATF | ASGE - LACF 1 | ASHA - GACH | ASHA - GBCH | ASHA - LACH | ASHA - LATF | ASHE - GACH | ASHE - LACH | ACG - UiA-LM | ARG - A/R | ARG36ALD3 | ARG - ALC | ARG45ALC3 | ARG18ALCH (Check RC remote) | ARG60AUGA | ARG90ELC3 (Check RC remote) | ARG90TLC3 (Check RC remote) | ARG - RLC | ARG - RLC3 | ARG - UU | ARG60AUAK (Check RC remote) | ARG60FUAK (Check RC remote) | ARG60FUAL (Check RC remote) | ARG - FUAN (Check RC remote) | ARG60RUAK (Check RC remote) | ARG60UUAK (Check RC remote) | ARG18UUAL (Check RC remote) | ARG60UUAN (Check RC remote) | ARG - FMTA | ARG - FHTA | ARGG - LLLB-A | ARGG - LMLA-A | ARGG24LMTA | ARH - LUAN | ARH - UUAN | ARHA - LB | ARHA45LC | ARHA - LBTU | ARHA - LCTU | ARHC - LC | ARHC - LCTU | ARHC - LHTA | ARHF24LB | ARHF - LBLU | ARHF - LBTU | ARHG - LHTA | ARHG - LLTA | ARHG - LLTB | ARHG - LM | ARHG - LMLA | ARHG - LMLE | ARSA - UHTB | ARSA - UMTA | ARSA - UMTB | ARYG - LMLE | ARXD - GALH | ARX - GBTH | ARXK - GCLH | MSAR - RIY(N) | AR - UFAAR | ARXA - GALH | ARXA - GBLH | ARXA - LALH | ARXA - LALR | ARXA - LATF | ARXA - LATH | ARXA - LBLR | ARXB - GALH | ARXB - LALF | ARXB - LALH | ARXB - LATF | ARXB - LATH | ARXB - LATR | ARXC - GATH | ARXC - GBTH | ARXC - LATF | ARXC - LATH | ARXD - LATH | ARXH - GTAH | AUG - Ui A-LR | AUG - Ui MI | AUG - UU | AUG - UUAS | AUGA - FRTA | AUGG - LVLA-A | AUGG - LRLA-A | AUH - LUAS | AUHA - LB | AUHA - LBLU | AUHA - LC | AUHA - LCLU | AUHF - LAL | AUHF24LB | AUHF - LBL | AUHG - LV | AUHG18LV | AUHG - LVLA | AUHG - LVLB | AUHG - LR | AUHG - LRLA | AUHG - LRLE | AUTG - LVLA | AUTG - LVLG | AUH - LUAR | ABHA - GATH | AU - UFAAR | AUG - UFARR | AUG - UFASR | AUGA - LATF | AUXA - GALH | AUXA - LALH | AUXB - GBLH | AUXB - GALH | AUXB - LALH | AUXB - LATF | AUXD - GALH | AUXD - LALH | AGHF - LA | AGHF - LAC | AGHG - LV | AGHG - LVCA | AGHG - LVCB | ABHF24LB | ABHG - LVTB | ABGA - LATF | ABHA - GATH | ABHA - LBTH | ABGG - LRTA-A | ABGG - LVTA | ABGG - LVTA-A | ABHA - LB | ABHA - LBT | ABHA45LC | ABHA - LCT | ABHF - LBT | ABHG - LR | ABHG - LRTA | ABHG - LRTE | ABHG - LVTA | AWGA - LATF | ASHA - LEC | ASHA - LKC | ASHG - LE | ASHG14LE | ASHG - LECA | ASHG14LECA | ASHG - LECB | ASHG - LJ | ASHG - LMCA | ASHG - LT | ASHG - LTCA | ASHG - LTCB | ASHG - LUCA | ASHG - LJCA

HIYASU AC models

HSA - LKC | HSB - LDC | HSG - LECA | HSG - LJCA | HSG - LFCA | HSG - LFCC | HSG - LMCA | HSG - LTCA | HSG - LUCA | ACH - H UiA-LH | ACH - H UiAT-LH | ACH - UiA-LL | ACH - UiA-LM | ACH - UiAT-LM | HR - UA | HRA - LALU | HRA - LATN | HRA - LATU | HRA - LBTU | HRA - LCTU | HRC - LCTU | HRF - LALU | HRF - LBLU | HRF - LBTU | HRG - LHTA | HRG - LLTA | HRG - LLTB | AUH - UiA-LR | AUH - UiAT-LR | AUH - UiA-LV | HU - UA | HUA - LATN | HUA - LATU | HUA - LBLU | HUA - LCLU | HUF - LAL | HUF - LBL | HUG - LVLA | HUG - LVLB | HUG - LHLE | HUG - LHLA | ABH - UiA-LR | ABH - UiAT-LR | ABH - UiA-LV | HGF - LAC | HGG - LVCA | HGG - LVCB | HBA - LBT | HBA - LCT | HBF - LBT | HBFF - LBT | HBG - LRTA | HBG - LRTE | HBG - LVTA | HBG - LVTB | HSA - LKC | HSG - LECA | HSG14LECA | HSG - LJCA | HSG - LMCA | HSG - LTCA | HSG - LUCA

* The asterisks stand for any character in the asterisk' position.

ORDER CODE:

INKNXFGL001R000	Fujitsu RAC and VRF systems to KNX Interface with binary inputs (to remote controller) - 1 unit
-----------------	---

INCLUDED COMPONENTS:

- Intesis Gateway.
- Installation Manual.

Warranty: 36 months.

Copyright © 2020 HMS Industrial Networks - All rights reserved.
