PC set OBELISK top2/3

Item no.: 9070409



Accessories Software

Description

- Switching programs created on the PC by means of the convenient OBELISK top2/3 software can be transferred via USB interface to the OBELISK top2 memory card or the Bluetooth OBELISK top3 and from the card to the time switch and vice versa. Thus no PC or laptop is required on-site. Programming and the program printout can be done comfortably from the desk
- For Windows Vista/7/8/10 (32/64 Bit)
- Consisting of: Memory card, USB plug adapter
- The OBELISK top2/3 software is available as free downloads at www. theben.de

