# KNX push-button BCU, switch position, WG 800



| | |
|---|---|
| **Reference number:** | 8471.01 LED W |
| **EAN/GTIN:** | 4011377086579 |

ELEKTROGERÄTE RÜCKNAHME

Depending on the version of the push-button BCU – 1-gang rocker or 2-gang rocker – centre plates are used with and without indication lights.
The “upper” or “lower” rockers can be controlled with the push-button with “neutral position”, while only the “lower” rocker can be pressed with the push-button with “switch position”. The push-button BCU can only function with an application program i.e. the push-button BCU consists of the device (hardware) and the application program (software).
Function: switching, dimming
LED: always ON, always OFF
KNX medium: TP 256

Can operate one group.
The status LED serves as orientation light or status indication.

**ALBRECHT JUNG GMBH & CO. KG**
Volmestraße 1
58579 Schalksmühle

Phone +49 (0) 23 55/80 60
E-Mail kundencenter@jung.de